



Buttons. There are four buttons around the rim of your new watch.

S1, at the 2 o'clock position, referred to as Talk.

S2, at the 4 o'clock position, called Mode.

S3, At the 8 o'clock position, called Hour.

S4, At the 10 o'clock position, called Minute.

Tactile display

" The watch lid lifts up at the 6 o'clock position, allowing you to determine the current time by lightly touching the hands(not push hands) and dots on dial"

" The tactile markings around the dial help show exactly where the hands are pointing. When done, snap the lid back into place."

" To set the hands, pull out the stem at the 3 o'clock position. Rotate the stem clockwise until the correct time is reached, then press the stem back in."

Setting Time. Press the Mode button once to enter the time-setting menu. Press Hour and Minute until the correct time is spoken.

Setting Alarm. Press the Mode button a second time. Press Hour and Minute until the correct alarm time is spoken.

Setting Features. Press the Mode button a third time. Press Hour to toggle hourly report. One clear louder beep indicates time will be announced hourly, two clear louder beeps indicates clock will chime every hour from 7 AM to 9 PM, and one lower beep indicates hourly report is off. Press Minute to toggle the Alarm. One beep indicates the alarm is on, no sound indicates the alarm is off.

Normal Operation. Press Talk whenever you want to hear the current time.

Press Hour to toggle between 12 and 24-hour format. A clear louder beep is heard,12-hour format is selected. No beep sound, 24 hour format is selected

Press Minute to select your favorite alarm sound (English talking watch with more than one alarm sounds, other language only beep available).

When the alarm goes off, Press Talk to snooze for ten minutes, or press Mode to stop the Alarm.

Happy time-telling!