

REIZEN™

3 n 1 Dual Voice Talking Cube Clock Instruction of 7025631 Talking Cube Clock

1. In normal time, press the top triangular buttons to activate voice chip to speak time and date.
2. In normal time, press "CALENDAR" to activate voice chip to speak the calendar.
3. Switch "HI" and "LOW" to control the volume.

4. To Set Female or Male Voice

Press "Reset" button once at the back, then Press "Time" button to change mode status circularly between female voice or male voice. Once the female voice or male voice is selected then press "Date" button or any other button to confirm.

5. Press and hold "MODE" button to change mode status circularly as following:

Chime on/off setting → Alarm sound setting → Alarm hour setting → Alarm minute setting → Year setting → Month setting → Date setting → Time hour setting → Time minute setting → 12/24 hour setting → Countup Timer on/off setting → Countdown Timer hour setting → Countdown Timer minute setting → Normal time.

6. Chime on/off setting

Press "MODE" to enter chime on/off setting mode, (it will speak the existing chime setting), Press "SET" to select either chime on or chime off.

7. Alarm on/off setting

Press "MODE" under normal time display to set either alarm on or alarm off.

8. Alarm sound setting

Press "MODE" to enter alarm sound setting mode, (it will sound the existing alarm sound), press "SET" to choose any 3 of alarm sound either "Dong Dong", or "Rooster", or "Bi Bi"

9. Alarm time setting

- a. Press "MODE" to enter alarm hour setting mode, press "SET" to set alarm time hour.
- b. Press "MODE" to enter alarm minute setting mode, press "SET" to set alarm time minute.

10. Calendar setting

- a. Press "MODE" to enter year setting mode, press "SET" to set year.
- b. Press "MODE" to enter month setting mode, press "SET" to set month.
- c. Press "MODE" to enter date setting mode, press "SET" to set date.

11. Time setting

- a. To set the talking voice time, press "MODE" to enter time hour setting mode, press "SET" to set hour time.
- b. Press "MODE" to enter time minute setting mode, press "SET" to set minute time.

12. 12/24 Hour setting

Press "MODE" to enter the 12/24-hour setting, (it will speak the existing setting), press "SET" to select either 12 hour time system or 24 hour time system.

13. Timer setting (Count Down)

- a. Press "MODE" to enter timer hour setting mode, press "SET" to set the timer hour.
- b. Press "MODE" to enter timer minute setting mode, press "SET" to set the timer minute.
- c. Press "CALENDAR" to activate count down timer on. When timer is on, the count down is in progress, press "CALENDAR" it will stop and report the remaining count down time. Press "CALENDAR" again to continue the countdown timer. When the count down timer is off, press "SET" can reset the count down timer.
- d. Press the top triangular "TIME" button to announce the remaining count down time.
- e. Press the top triangular "DATE" button to stop the timer anytime and resume it when press again.
- f. When count down reach to the last 10 second, it will announce 9, 8,.....1, 0 and then it will have "Beep Beep" sound followed by announce 0 hour 0 minute.
- g. Press any button to stop the "beep beep" voice.

14. Timer setting (Count Up)

- a. Press the top triangular "Calendar" button to start the count up timer.
- b. Press "Time" to announce the current count up time.
- c. Press "calendar" again or the top triangular "DATE" button to stop the timer.