

INSTRUCTION OF YL-645

- ♦ Rotate the button on the left to change mode status.
- ♦ Time announcement
Rotate the button to "TIME" to speak current time.
Press "M." to set chime function "on" or "off".
- ♦ Set time - Rotate the button to T.S. to set time.
In the time set mode, press "H." and "M." buttons to adjust the hour and minute individually until the correct time is displayed.
- ♦ Set alarm time - Rotate the button to A.S. to set alarm time.
In the alarm time set mode, press "H." and "M." buttons to adjust the alarm time.
- ♦ Disable alarm function - Rotate the button to ALM.OFF.
- ♦ Snooze function
When the alarm is on, it lasts one minute, to stop midway, press "Hour" or "Minute" key, if "Talking" is pressed while alarm, time will be announced once and alarm will stop and then start again in 10 minutes.
- ♦ In time display mode, press "Hour" key, could choose 3 alarm voices in cycle: (beep)>(cuckoo)>(crowcock).

*****ATTENTION*****

If the LCD screen fades and the sound becomes weak or the function is abnormal, please change the battery (CR2016x1)