



## Revive LED Floor Lamp

F1693009 F1693009-SHPR

F0095

### CONGRATULATIONS!

You've purchased the finest in natural lighting technology with your new OttLite® product.

### PRODUCT REGISTRATION FORM

Please complete the enclosed Product Registration Form and return it today by mail, or register online by going to: [OttLite.com/warranty](http://OttLite.com/warranty)

**WARNING: To prevent electric shock, make sure the lamp is not plugged in until all assembly steps are complete.**

### LAMP ASSEMBLY

1. Unpack all lamp parts and lay out on the floor with base (A) laying flat.
2. Thread pole (B) to base (A) by hand turning clockwise until tight.
3. Thread upper pole (C) to lower pole (B) by hand turning clockwise until tight.
4. Thread arm (D) into upper pole (C) by hand turning clockwise until tight. Pull excess cord along poles (B,C,D).
5. Connect the A/C Adapter input (L) into connector (M) of cord in the rear-bottom of pole (B).
6. Plug the A/C adapter (N) into a standard household 120V AC outlet. **Note: Only use with the supplied AC adapter to avoid damage or fire.**
7. Turn the lamp ON & OFF using power switch (E) located in the upper side of shade (F). Power switch (E) is a "touch" switch that controls the dimmer function for 3 levels of brightness.
8. To power LED settings, slightly touch the switch (E) to achieve the following:
  - turn lamp "ON" to 1st lower brightness; touch the switch "once"
  - for medium-brightness; touch the switch "twice"
  - for high-brightness; touch the switch "three-times"
  - to turn lamp "OFF"; touch the switch "four-times"
9. To adjust height and angle of the shade (F) and arm (D), turn thumbscrews (H, J, K) counter clockwise. Adjust to desired height and angle then tighten thumbscrews (H,J,k) by turning clockwise. **DO NOT OVERTIGHTEN** as this would strip the thread.

### SAFETY WARNING: TO REDUCE THE RISK OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS

1. Turn lamp off and **WAIT UNTIL LAMP HEAD (F) AND ADAPTER (N) ARE COOL** before handling.
2. The LED panel (G) might get hot after several hours of continuous use, **DO NOT** place your hands directly on LED light panel.
3. Never use with an extension cord unless the plug can be fully inserted into the receptacles in the extension cord.
4. Do not alter the plug.
5. The lamp head included with this unit cannot be replaced by the consumer.

**NOTE:** The important safety instructions appearing in this instruction sheet are not meant to cover all possible conditions and situations that may occur. It must be understood that common sense, caution, and care must be used with any electrical product.

**CAUTION!** IF THE EXTERNAL FLEXIBLE CABLE OR CORD OF THIS LUMINAIRE IS DAMAGED, IT SHALL BE EXCLUSIVELY REPLACED BY THE MANUFACTURER OR ITS SERVICE AGENT OR A SIMILAR QUALIFIED PERSON IN ORDER TO AVOID A HAZARD. INDOOR USE ONLY.

### FCC PART 15

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that the interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that of the receiver.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

**CAUTION:** ANY CHANGE OR MODIFICATION TO PRODUCT NOT EXPRESSLY RECOGNIZED BY OTTLITE TECHNOLOGIES VOIDS OTTLITE'S RESPONSIBILITY FOR PROPER FUNCTION OF PRODUCT.

### CAN ICES-005 (B)/ NMB-005 (B)

#### AC/DC ADAPTER

Input: AC 100-240V, 50/60 Hz, 0.5A  
Output: 24V DC, 700mA with a Male DC Plug