

SW-5D Talking Alarm Watch

1. Set Mode
 - a. Push SET button Once: ALARM ON
 - b. Push SET button Twice: Time Set
 - c. Push SET button Triple times: Alarm Time Set
 - d. Push SET button Fourth times: Alarm Off

2. To know the time
 - a. Press the “Talk” button on the upper right side of the watch to hear time announcement.

3. How to set current time
 - a. Push the “Set” button Twice to enter the Set mode, the time digits flash
 - b. Push the “HR” button to increment the hour
 - c. Push the “MIN” button to increment the minute
 - d. Push the “SET” button Once to enter next Alarm Set Mode
 - e. If you don’t push SET button for 7 sec. then display will be back to normal time automatically

4. To select Alarm Sound
 - a. Under normal time, push “HR” button to select 3 different alarm sounds.

5. To set Alarm Time
 - a. Push the “SET” button three times to enter the alarm time set mode, the time digits flash and display show “AL”
 - b. Push the HR button to increment the alarm Hour.
 - c. Push the MIN button to increment the alarm minute
 - d. After setting for 7 sec. the display will be back to normal time automatically

6. To set Alarm On/Off
 - a. Push the SET button once, to se alarm on and display show “Bell” symbol
 - b. Push the SET button four times to set Alarm off and “Bell” symbol disappears

7. To Operate Snooze
 - a. While alarm is ringing, press “TALK” button to activate snooze and “BELL” symbol flashing. The alarm will ring again after 10 minutes.

8. To turn off Snooze
 - a. Keep alarm ringing for one minute, to stop alarm and snooze automatically.
 - b. Or during alarm to push the HR or MIN button, to stop snooze function

9. How to change the battery
 - a. Screw out the battery cover on the back of the watch
 - b. Then screw out the battery contact to take out the battery

- c. Change a new battery CR2032 or equivalent 3V lithium battery. “-“ minus polarity face up and “+” plus polarity face down.
 - d. Put back the battery cover with screw driver
-
10. Use a pointed object such as a paper clip to push the following buttons:
 - a. “SET” button on the lower right side of the watch
 - b. “HR” button on the upper left side of the watch
 - c. “MIN” button on the lower left side of the watch