

Inserting the Batteries For The Coil Auto-Touch Magnifilers

- 1. The magnifier requires 2 AA size batteries.
- 2. The battery compartment is accessed by opening the bottom of the handle. Press the middle portion of the bottom of the handle and the hinged battery cover will open.
- 3. Insert 2 AA batteries. The battery on the right side of the terminall will be inserted with the Positive end positioned toward the Magnifier lens. The battery on the left side of the battery compartment will be inserted with the negative end positioned towards the lens.
- 4. There is a small etched diagram of the proper battery insertion method on middle section of the bottom of the handle.